

USB HOST Function for VP5x00 to transfer data directly from USB flash drive



Firmware **OA-0.8.3-B16**

For MODEL: VP5500/5700

USB HOST Function for VP5x00 to transfer data directly from USB flash drive

OA-0.8.3-B16 is a beta version and we are still working on and invite regular users to test out. We can't promise all kinds of USB flash drive will work and will not cause VP5500/5700 hang under this beta version.

We'd strongly recommend customers in other markets try and use this firmware - and we'd expect it will improve and advance the performance.

How To Use USB HOST Function (VP5500/VP5700)

Firmware Version : 0A-0.8.3-B16

Steps:

1. Switch on the device and press  [Menu] button

Note: The default of USB Host is USB Off and please makes sure the USB Host is On before start this function.



2. Press OK of the Joystick to enter USB Host mode and a USB Flash Drive icon will appear at the bottom of the display.





For : serial number 1001~4271

Note: when turn on the USB Host function, the red LED will flash to make sure the battery is fully charged in case low battery causes data transferring failed or device hang.

3. Plug USB flash drive to the specific USB Host cable and then connect to VP5x00.
The display will show USB icon to tell you that device has recognized your USB Flash Drive.



4. To off the USB host function, please press  [Menu] button and press down the Joystick to Off USB Host mode.



If you have any questions or comments, please feel free mail to service@vosonic.com.tw
VOSONIC Technology Corporation Homepage: www.vosonic.com
7F1., No.159 ,Hsien-Cheng 9th Road, Chu-Pei City , Hsi-Chu, Taiwan
TEL:886 3 555 7745 FAX:886 3 555 0390